




Evaluation of Activated Carbon for Environmental Remediation Applications

Andy Harris, P.E., Senior Applications Engineer
April 2022

Outline

1. Adsorption equilibrium
2. Adsorption kinetics
3. Significance of kinetics on cap designs
4. Demonstration test: impact of carbon particle size on adsorption

Adsorption Equilibrium and Kinetics




Transient (unsteady state): $r_a \neq r_d$

Equilibrium (steady state): $r_a = r_d$

Equilibrium Loading Capacity \longrightarrow Carbon Consumption


Kinetics



Factors Affecting Equilibrium Loading Capacity


Adsorbate

- Concentration
- Solubility
- Molar Volume
- Polarizability
- (Background Organics)




Adsorbent

- Base Material
- Degree of Activation




Evaluating Equilibrium Loading Capacity



Isotherm (ASTM D 3860)




Naphthalene on F300



Column Test



Evaluating Equilibrium Loading: Common Pitfall




Peel et al. 1980; Randtke et al. 1983


- Not waiting long enough to approach equilibrium
- Not pulverizing the carbon (e.g., 95% -325 mesh)

Kinetics

Diffusion Processes




Mass Transfer Zone (MTZ)




Characteristics That Increase the Rate of Adsorption

- ↓ Carbon Particle Size (most important)
- ↑ Contaminant Diffusivity (Ficks's Law: $J = -D \frac{dC}{dx}$)
- ↑ Water Temperature (↓ Viscosity)
- ↑ Transport Pore Volume (between 1,000 and 100,000 Å, when bulk diffusion through large pores is limiting)


Significance of Kinetics in Cap Designs



Impact of Particle Size on Adsorption



Test Conditions:
Adsorbate = naphthalene
Solvent = distilled water
Co = 8 mg/L
Carbon dose = 50 mg/L
Sample volume = 1000 mL
Analysis: UV spectroscopy



GAC = F300 8x30



PAC = F300 sized to 95% -325 mesh

Summary

- Equilibrium loading capacity is fundamental to all activated carbon applications
- Take care when evaluating capacity: particle size and contact time will impact results
- Adsorption kinetics may be significant for some applications, but not for all

Thank you.

